

# **USB 3.1 Gen2 Type-A to 2.5” SATA 6G Cable**

## **User Manual**

**Ver. 1.00**

**All brand names and trademarks are properties of their  
Respective owners.**

# Contents:

<b>Chapter 1: Introduction .....</b>	<b>3</b>
1.1 Features.....	3
1.2 System Requirements .....	3
1.3 Package Contents.....	4
<b>Chapter 2: Getting Started .....</b>	<b>4</b>
2.1 Hardware Overview.....	4
2.2 Hardware Installation .....	5
2.3 Driver Installation.....	5

# Chapter 1: Introduction

## ***1.1 Features***

- Compliant with USB 3.1 Specification Revision 1.0
- Compliant with USB Specifications Revision 2.0
- Support USB Super-speed Plus, USB Super-Speed, High-Speed and Full-Speed Operation
- Support USB Mass Storage Class, Bulk-Only Transport Specification Revision 1.3
- Support USB Attached SCSI Protocol Specification Revision 1.0
- Compliant with Serial ATA Specification Revision 3.2
- Bus bandwidth of Serial ATA up to 6Gbps
- Supports SATA 2.5” hard drives or SSD
- LED to indicate drive power and activity

## ***1.2 System Requirements***

- Windows® 7/8/8.1/10 (32/64 bit)
- Available USB 3.0/3.1 Type-A port

## 1.3 Package Contents

- 1 x USB 3.1 Gen2 Type-A to 2.5" SATA 6G Adapter
- 1 x User Manual

## Chapter 2: Getting Started

### 2.1 Hardware Overview



## ***2.2 Hardware Installation***

**Note:** The USB 3.1 Gen2 Type-A to 2.5” SATA 6G Adapter only works with 2.5 in. HDD and SSD, because 3.5 in. HDDs and optical drives require 12V of power and the adapter only provides 5V of power.

1. Connect the SATA connector on the adapter to the SATA receptacle on your 2.5 in. SATA HDD or SSD.
2. Connect the USB 3.1 connector on the adapter to a USB port on the host computer system.

## ***2.3 Driver Installation***

After the adapter is attached to a computer, the necessary software automatically installs and the drive is accessible as through it were installed internally in the system.